



PLEASE READ BEFORE USE

INTRODUCTION

Your Caller ID phone stores and displays specific information, provided by your local telephone company, to subscribers of Caller ID or similar caller identification services.

Your Caller ID phone enables you to:

- Identify callers before you answer the phone.
- View the time and date of each incoming call.
- Record up to 80 Caller ID name and number messages sequentially.

MAIN FEATURES

- FSK/DTMF auto detect.
- Call Waiting Caller ID (FSK Type II).
- LCD Contrast adjustable
- Record up to 80 incoming caller names and numbers.
- Record up to 25 recent dialed numbers.
- 10 two-touch memories and 8 one-touch memories.
- Message waiting indicator
- Redial.
- Pulse or Tone dialing mode.
- Flash timing selectable. (100/300/600/1000ms)
- Mute function.
- Speakerphone.

*Caller ID requires subscription to your local telephone company.

SHORT GLOSSARY OF TERMINOLOGY USED IN THIS MANUAL


Hook switch. The part of the phone that pops up to activate the phone line when the handset is lifted from the base.

Off-hook. The phone is in active mode when the handset is off the base cradle or the **SPEAKER** feature is on.

On-hook. The phone is in standby mode when the handset is on the base cradle.

PARTS CHECKLIST

Make sure your package includes the items:




NOTE: If there is any item missing in the package, please contact the shop where you bought this product.

INSTALLING THE BATTERIES

Your Caller ID phone uses 3 AA-Size alkaline batteries for receiving and storing Caller ID records.


Install 3AA-size alkaline batteries into the compartment and re-fit the cover before use.




IMPORTANT: If you are not going to use the telephone for more than 30 days, remove the batteries.

WALL MOUNTING


1. Rotate the wall mounting knob as shown below:



WALL MOUNTING: The knob is designed to keep this unit in place when the telephone is vertical on the wall.




OPTIONS MENU




SETTING THE PHONE

NOTE: Program the following settings before using the phone.


There are 6 options to set:



SETTING DATE/TIME




SETTING LOCAL AREA CODE




The area code prior to an incoming number will be removed from the caller ID display if it matches with the area code you set.


SETTING LONG DIST CODE




SETTING LANGUAGE



SETTING FLASH TIME




SETTING TONE/PULSE




PHONE OPERATION

RECEIVING A PHONE CALL




MAKING A PHONE CALL



CONTRAST LEVEL ADJUSTMENT

Press the CONTRAST button to adjust the display contrast level.

REDIAL



MUTE


Press the MUTE button to mute a call, when mute is on, the mute indicator will show on the screen. Press the MUTE button again to resume normal conversation.

SPEAKER VOLUME LEVEL ADJUSTMENT

User may adjust speakerphone volume level during conversation by pressing the VOL button.

RINGER VOLUME LEVEL

Use the ringer volume switch indicated as A on the picture shown below to select the ringer volume from ON (A) or OFF (B).



HEADSET OPERATION

The headset operation is the same as the speakerphone operation. When the headset is plugged in, pressing the SPEAKER button will take line and activate the headset. Conversation can begin using the headset. Pressing the SPEAKER button again will release the line and deactivate the headset. During headset conversation, picking up the handset will automatically transfer the conversation to handset. Returning the handset after conversation will release the line.

Using the Headset Feature

Your HANDSET, when connect to a headset (not included), will provide you with hands-free communication.


Headset jack specification-2.5mm connector
(compatible to panasonic Headset)

CALLER ID FEATURES

Caller ID (CID) is a service provided by your local telephone company. You have to subscribe this service from your local telephone company before you can use it.



This unit can receive caller ID without any setting. Your caller ID information may include the phone number, name, date and time.

REVIEWING INCOMING CALLS



Reviewing incoming call log

DIAL BACK A CALLER ID NUMBER




NOTE: Press the # button to display different dialing options of a caller ID number.


DELETING A CALLER ID NUMBER




DELETING ALL CALLER ID NUMBER




REVIEWING OUTGOING NUMBERS




DIAL BACK AN OUTGOING NUMBER




DELETING AN OUTGOING NUMBER




DELETING ALL OUTGOING NUMBER




STORING A TELEPHONE NUMBER




STORING AN INCOMING CALL NUMBER




STORING AN OUTGOING NUMBER INTO MEMORY




DIALING A MEMORY LOCATION



CHECK CONTENT OF MEMORY LOCATION



DELETING A MEMORY LOCATION



TROUBLESHOOTING TIPS

No Dial Tone

- Check all connections are secure and not damaged.
- Make sure the hook switch is fully extended when the handset is lifted from the cradle.

The Telephone Does Not Display Caller ID information

- Make sure you have subscribed to caller ID service from your local telephone company.
- Depending on telephone company, the caller ID information may not display until the second ring of an incoming call.

The Phone Does Not Ring

- You may have too many extension phones on one line. Try to unplug some extension phones.

Incoming or Outgoing Voice Volume is Low

- Make sure no other phone on the same line is off hook at the same time as it will influence the voice volume.
- Check the handset receiver or speaker volume.

SAFETY INSTRUCTIONS

Take special care to follow the safety suggestions listed below. Please do not use telephone during thunderstorm.

Installations Environment

- Avoid placing it near heating appliances and devices that generate electrical noise (for example, motors or fluorescent lamps).
- DO NOT expose to direct sunlight or moisture.
- Do not install the telephone during thunderstorm.
- Clean with a soft cloth.
- Never use a strong cleaning agent or abrasive powder because this will damage the unit.
- Avoid dropping the handset, as well as other rough treatment to the phone.

Placement

1. Do not place heavy objects on top of this unit.
2. Care should be taken so that objects do not fall onto, and liquid into, the unit. Do not subject this unit to excessive smoke, dust, mechanical vibration or shock.

WARNING: To prevent fire or shock hazard, do not expose this product to rain or any type of moisture.

For sales and service in Asia
Contact: info@ustel.com.hk
AS7403 IB Rev.2

18.COM Electronics Pte Ltd.

WARRANTY CARD

Name: _____

Contact No. Tel: _____

Model: _____

Date Of Purchase: _____

Serial No.: _____

Dealer's Stamp: _____

Service Centre:
Monday- Friday Opening Hours
9:30am - 12:30pm, 2:00pm - 5:00pm
Tel: 6278 8274

CUSTOMER'S COPY : DO NOT MAIL THIS

1. This warranty starts on the date of purchase and expires in 1 year. Customer must bring along this warranty card and original invoice or receipt together with the complete product for any repair services.
2. Any warranty application with no invoice and/or warranty card are regarded as invalid warranty. Customer must pay for repair charges.
3. This warranty is invalid if the product has been modified, altered and / or repaired by persons other than technician of our company or mishandled by customer.
4. This warranty is applicable to Singapore only.
5. This warranty does not cover damages caused by natural disasters such as flooding and lightning etc.
6. Customers are requested to collect repaired unit within two months from date of submission. Units not collected after 6 months will be disposed off by the company.

18.COM Electronics Pte Ltd, 159 Sin Ming Road, Amtech Building, #04-01, Singapore 575625