




AT4401

2-Line Cordless Answering System
with Smart Call Blocker



Quick start guide


What's in the box




Connect and install

1 Connect the telephone base


If you subscribe to digital subscriber line (DSL) high-speed Internet service through your telephone line, make sure you connect a DSL filter (not included) to the telephone wall jack.



2 Install the battery



3 Connect the charger



4 Charge the battery



Display Handset:

	The battery is low and needs charging.
	The battery is charging.
	The battery is fully charged.
	Line 1 or line 2 is in use.
	Handset ringer on line 1 and/or line 2 is off.
	New voicemail received on line 1 and/or line 2 from your telephone service provider.
	There are new answering system message(s) on line 1 and/or line 2.
	ANSI CH2
	The microphone is muted.
	New caller ID log entries.
	Option displayed above a softkey. Press or to select.

Telephone base:

	Line 1 or line 2 is in use.
	Telephone base ringer on line 1 and/or line 2 is off.
	New voicemail received on line 1 and/or line 2 from your telephone service provider.
	There are new answering system message(s) on line 1 and/or line 2.
	The microphone is muted.
	New caller ID log entries.
	Option displayed above a softkey. Press or to select.

IMPORTANT

Are you a new cable or VoIP subscriber?
If your answer is **yes**, the existing telephone jacks in your home may no longer work. Your cable/VoIP service provider uses a different connection, separate from your old traditional telephone service, to connect the modem/router/terminal adapter installed in your home.

To allow all existing telephone jacks to work, contact your telephone service provider for solutions, such as rewiring services (fees may apply).

If your answer is **no**, your existing telephone jacks will continue to work as normal.

Did you subscribe to voicemail service from your telephone service provider?

Some telephone service providers bundle or combine multiple services like voicemail and call waiting, so you may not be aware that you have voicemail. To check what services you have and how to access them, contact your telephone service provider.

Use the voicemail service only


To use your voicemail service rather than your answering system, turn off your answering system.

Use the answering system only
To use your answering system rather than your voicemail service, contact your telephone service provider to deactivate your voicemail service.

Use the answering system and voicemail together
You can also use your telephone answering system and voicemail together by setting your built-in answering system to answer before voicemail answers as described below. To learn how to program your voicemail settings, contact your telephone service provider.

If you are on a call, or if the answering system is busy recording a message and you receive another call, the second caller can leave a voicemail message.

Set your answering system to answer calls at least two rings earlier than your voicemail is set to answer. For example, if your voicemail answers after six rings, set your answering system to answer after four rings. Some voicemail providers may program the delay before answering calls in seconds instead of rings. In this case, allow six seconds per ring when determining the appropriate setting.



2 Setup

After you install your telephone or power returns following a power outage and battery depletion, the handset and telephone base will prompt you to set the date and time, and to configure the Smart call blocker and answering system through voice guide.

Date and time

Follow the steps below to set the date and time. For example, if the date is 25 July, 2018, and the time is 12:05 PM:




When the handset and telephone base prompts you to set the date and time



Voice guide for Smart call blocker

After setting the date and time, the handset and telephone base will prompt if you want to set Smart call blocker. For more details, see **Use voice guide to set Smart call blocker** in the **Introducing Smart call blocker** leaflet.

When the handset and telephone base prompt you to set up the Smart call blocker via voice guide



"Hello! This voice guide will assist you with the basic setup of Smart call blocker"

Setup your Smart call blocker by inputting the designated numbers as instructed in the voice guide.

Voice guide for answering system

After setting the Smart call blocker, the handset and telephone base will display **Start voice guide to set up Answering system now?**

This feature assists you to do the basic setup of the answering system. You can follow the voice guide to record your own announcement, set the number of rings and the message alert tone.

When the handset and telephone base prompt you to set up the answering system via voice guide




Choose a specific line

"Hello! This voice guide will assist you with the basic setup of your answering system"


Setup your answering system by inputting the designated numbers as instructed in the voice guide.

3 Operate


Make a call




Answer a call



End a call



Volume



Distributor:
US TELECOM LIMITED
info@ustel.com.hk
www.ustel.com.hk


Technical specifications

Frequency control	Crystal controlled PLL synthesizer
Channels	5
Normal	Actual operating range may vary according to effective range
Power requirement	Handset: 2.4V Ni-MH battery Telephone base: 6V DC @ 600mA Charger: 6V DC @ 450mA
Memory	Phonebook: 50 memory locations; up to 30 digits and 15 characters Caller ID log: 50 memory locations; up to 24 digits and 15 characters Call block: 1000 entries

Caller ID


If you subscribe to caller ID service, information about each caller appears after the first or second ring. The caller ID log stores up to 50 entries. Each entry has up to 24 digits for the phone number and 15 characters for the name.

Review caller ID log entries




Save a caller ID log entry to the phonebook

When your desired caller ID entry displays on the handset or telephone base screen




Dial a caller ID log entry

When your desired caller ID entry displays on the handset or telephone base screen



Delete a caller ID log entry


When your desired caller ID entry displays on the handset or telephone base screen



Smart call blocker

If you have subscribed to caller ID service, you can use the Smart call blocker feature to screen incoming calls. Smart call blocker is on, and to allow all incoming calls by default. CID works in FSK environment only. Call Block function may or may not be compatible to your local telecom operator.

Turn the Smart call blocker on or off



For more details, refer to the **Introducing Smart call blocker** leaflet.


How to unblock a telephone number?

- Press **CALL BLOCK** when the phone is not in use. **-OR-** Press **MENU** when the phone is not in use. Press **VOLUME DOWN** or **VOLUME UP** to scroll to **Smart call blk** and then press **SELECT**.
- Press **SELECT** to choose **Block list**.
- Press **SELECT** to choose **Review**.
- Press **VOLUME DOWN** or **VOLUME UP** to browse through the call block list.
- When the desired entry displays, press **DELETE**. The screen displays **Delete entry?** and the name of the entry.
- Press **YES** to confirm. The screen shows **Entry deleted**, and you hear a confirmation tone.


Phonebook

The phonebook can store up to 50 entries, which are shared by all handsets and the telephone base. Each entry may consist of a telephone number up to 30 digits, and a name up to 15 characters.

Add a phonebook entry




Review phonebook entries




Delete a phonebook entry

When your desired phonebook entry displays on the handset or telephone base screen




Speed dial


The telephone system has 10 speed dial locations where you can store the telephone numbers you wish to dial more quickly. All speed dial assignments can only be selected from the existing phonebook entries.



Assign a speed dial entry



Dial a speed dial entry



*The 10 speed dial keys represents speed dial locations, 1-9 and 0, from top to bottom.


About the built-in answering system and voicemail service

For message recording, your telephone has a built-in answering system, and it also supports voicemail service offered by your telephone service provider (subscription is required, and fee may apply).


Built-in answering system VS Voicemail service

	BUILT-IN ANSWERING SYSTEM	VOICEMAIL SERVICE
SUPPORTED BY	Telephone system	Telephone service provider
SUBSCRIPTION	No	Yes
FEES	No	May apply
ANSWER INCOMING CALLS	<ul style="list-style-type: none"> After 4 rings by default. It can be changed in the handset or the telephone base menu. 	<ul style="list-style-type: none"> Usually after 2 rings. It can be changed by contacting your telephone service provider.
STORAGE	Telephone base	Server or System
DISPLAY NEW MESSAGES	<ul style="list-style-type: none"> Handset - QD and XX New Msg Telephone base - QD and XX New Msg 	<ul style="list-style-type: none"> Handset - MAIL Telephone base - MAIL
RETRIEVE MESSAGES	<ul style="list-style-type: none"> Press MAIL on the telephone base; OR Press MENU, and then select Play messages on the handset; OR Access remotely with an access code. 	<ul style="list-style-type: none"> Press MAIL on the dialpad, and enter an access number and/or passcode from your telephone service provider.


Turn the built-in answering system on or off




Message playback on the telephone base




Skip a message



Repeat the playing message



Play the previous message



Delete all messages

